## How to configure env of capturing ECG's log

in this document, i will introduce how to configure the environment of capturing ECG log via debug board. we need the driver of NCM (\gcr9010201\proj\NJProj\PD\2.4\_PMT5 - EESE\PMT5-Systems\to rain\FNV2 SW\FordInstaller).

1) install the NCM driver

after installing ,it is high probability failure, The digital signature of the driver required for this device could not be verified.

the path to fix this problem is:

open "start" button - > click settings - > Update & Security - > Recovery - > Restart now - > troubleshoot - > Advanced Options - > Startup Settings - > Restart - > choose 7( Always press F7).

waiting for a minutes, after booting the driver will be ok



2) Browse to "Control Panel" and open "Network and Internet"



## Adjust your computer's settings

View by: Category ▼



System and Security
Review your computer's status
Save backup copies of your files with File History
Backup and Restore (Windows 7)



## Network and Internet

View network status and tasks

Choose homegroup and sharing options



Hardware and Sound View devices and printers

Add a device

Adjust commonly used mobility settings



Programs
Uninstall a program
Get programs



**User Accounts** 





Appearance and Personalization




Clock, Language, and Region Add a language

Change input methods
Change date, time, or number formats



Ease of Access Let Windows suggest settings Optimize visual display


3) Press the "Change Adapter settings" button, "Network Connections" windows opens up




- 4) on the "Network Connections" windows, observe the "Ford Motor Company Device", then Right click on the this device and click on "Properties"
- 5) In the properties ,press on the "Internet Protocol Version 4(TCP/IPv4)"
- 6) Select the " use the following  $\mbox{\sc lp}$  address" option and fill in the following details:

ip address: 192.168.10.100 (if error, you can change to other num, such as: 192.168.10.199)

subnet mask : 255.255.255.0



7) Install ULT.ext ,Then open the ULT to begin capturing logs for ECG /TCU/SYNC



over